

REAR CARRIER

| Accessory Name | Parts Number | Application Model | Issue Date | Publication No. | FRT |
|----------------|---------------|-------------------|------------|-----------------|-------|
| REAR CARRIER | 08L70-K0F-D11 | Z125M/MA | 2021.04 | MII | 0.2 H |

Introduction

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON Honda MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

Honda Dealer:

Please give a copy of these instructions to your customer.

Customer

Because it requires specialized knowledge and special tools and equipment, it is recommended to install it at a dealer with qualified automobile maintenance.

How To Read These Symbols

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual.

MARNING You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

A CAUTION You CAN be HURT if you don't follow instructions.

★NOTICE The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

NOTE Things you want to know, things that are useful to know.

Follow the instructions of the Service Manual.

Follow the other symbol instructions of the "Installation Instructions BASIC".

Instruction Other Symbols

The symbols used throughout this instructions show specific service procedures.

Refer to "Installation Instructions BASIC" for description of each symbol.

INFORMATION

ACAUTION

• To prevent burns, allow the engine, exhaust system, radiator, etc., to cool before installing the accessory.

NOTE:

• Take care not to damage the painted surfaces of the motorcycle.

PARTS LIST

When the instruction manual and installation instructions are included in this kit, be sure to give them to the customer.

| Component | No. | Parts Name | Qty | Parts No. |
|-----------|-----|------------------|-----|---------------|
| _ | (1) | Rear carrier | 1 | - |
| | (2) | 8 mm flange bolt | 2 | 95701-0801608 |
| | (3) | Caution label | 1 | - |
| (2) (3) | | | | |


TORQUE INFORMATION


| ITEM | N⋅m (kgf⋅m) |
|-----------------|-------------|
| 8 mm flange nut | 27 (2.8) |


Refer to the Service Manual for the torque values including standard torque of the removed parts. (III)


INSTALLATION











6. Install the motorcycle's parts in the reverse order of removal.